

Cushy Number

Stage Rider & Channel List

Kontakt:
 Martin Detig
 +41796612986
martin.detig@me.com

Power 230V iPad



Power 230V
 Amp Sim



Drums

Martin: Ch 1-8
 Monitor: Aux5 & no Wedge (->XLR to Martins personal inEar device)

Miks XLR:
 1 Bass Drum
 1 Snare Top
 1 Snare Bottom (Optional)
 1 HiHat
 2 Toms
 2 Overhead

Number and size of Boom Stands dependent of the miks

Bass Doug: Amp Sim XLR: Ch 9
 Monitor: Aux4 & Wedge

Eric sings: CH 14
 1 Mik XLR
 1 Boom Stand

Power 230V Guitar
 Amp Sim



Power 230V Guitar
 Amp Sim



Guitar Phil: Ch 10
 Phils personal Amp Sim, Jack Connector to local DI-Box to XLR
 Monitor: Aux2 & Wedge

Phil sings: CH 15
 1 Mik XLR
 1 Boom Stand

Tim Lead Voice:
 Monitor: Aux1 & Wedge

Tim sings: Ch 16
 1 Mik XLR
 1 Boom Stand

Monitor Wedge

Guitar Olaf: Ch 11
 Olafs personal Amp Sim, Jack Connector to local DI-Box to XLR
 Monitor: Aux2 & Wedge

Olaf sings: Ch13
 1 Mik XLR
 1 Boom Stand

Channel List:

Channel	Track	Processor
1	Kick	Gate/Comp
2	Snare top	Comp (no Gate)
3	Snare Bottom (Option)	Comp (no Gate)
4	HiHat	
5	Tom	Gate/Comp
6	Floor Tom	Gate/Comp
7	Overhead L	
8	Overhead R	
9	Bass Amp (Direct out)	Comp
10	Guitar Phil	Comp
11	Guitar Olaf	Comp
12		
13	Backing Voice Olaf	Comp/Eff
14	Backing Voice Doug	Comp/Eff
15	Backing Voice Phil	Comp/Eff
16	Lead Voice Tim	Comp/Eff

Return Channel List Monitoring:

Channel	Track
1	Monitor Tim
2	Monitor Phil
3	Monitor Olaf
4	Monitor Doug
5	Monitor Martin